

BALL VALVES

Female & Female Ball Valve

- B for blue color
- R for red color



| Connection | Part No. | Pressure (Bar) |
|------------|----------|----------------|
|------------|----------|----------------|

| | | |
|------------|-------------|----|
| BSP 1/2" | KV 001 - 21 | 20 |
| BSP 3/4" | KV 001 - 26 | 20 |
| BSP 1" | KV 001 - 33 | 20 |
| BSP 1 1/4" | KV 001 - 42 | 20 |
| BSP 1 1/2" | KV 001 - 48 | 20 |
| BSP 2" | KV 001 - 60 | 20 |

Female & Female Mini Ball Valve

- B for blue color
- R for red color



| | | |
|----------|-------------|----|
| BSP 1/4" | KV 002 - 13 | 16 |
| BSP 3/8" | KV 002 - 17 | 16 |
| BSP 1/2" | KV 002 - 21 | 16 |

Female & Male Mini Ball Valve

- B for blue color
- R for red color



| | | |
|----------|-------------|----|
| BSP 1/4" | KV 003 - 13 | 16 |
| BSP 3/8" | KV 003 - 17 | 16 |
| BSP 1/2" | KV 003 - 21 | 16 |

Female & Male Butterfly Handle Ball Valve

- B for blue color
- R for red color
- RB for both



| | | |
|----------|-------------|----|
| BSP 1/2" | KV 004 - 21 | 16 |
| BSP 3/4" | KV 004 - 26 | 16 |
| BSP 1" | KV 004 - 33 | 16 |

Female & Female Butterfly Handle Ball Valve

- B for blue color
- R for red color
- RB for both



| | | |
|----------|-------------|----|
| BSP 1/2" | KV 005 - 21 | 16 |
| BSP 3/4" | KV 005 - 26 | 16 |
| BSP 1" | KV 005 - 33 | 16 |